## DATA SHEET



### Dairy-RO4 Membrane

# **Product Description**

# Membrane Characteristics

Membrane material: PA

Outer wrap: Net

Application: Dairy concentrate

**Spacer:** 31/34/65 mil

Feature; Conform to 3A Standard

Product	Water Flux LMH	Salt Rejection /MgSO4	Salt Rejection /NaCl
DairyRO4	30	/	>99.5%

Test Conditions: 1) 2000 mg/L Nacl, 800psi (5.5Mpa),  $77^{\circ}F$  (25  $^{\circ}C$ ), pH6.5, 15% recovery

2) The flux of a single membrane element may vary in the range of  $\pm$  25%.

# **Product Specifications**


Model	Spacer (mil)	Membrane area (ft2/m2)	Outer wrap	
3838	31	75.(7.0)	Net	
3030	46	60 (5.6)	1101	
3840	31	75 (7.0)	Net	
	46	60 (5.6)		
6338	31	205 (19)		
	46	165 (15.3)	Net	
	65	125 (11.6)		
8038	31	310 (32.5)	•	
	46	260 (24.2)	Net	
	65	210 (19.5)		
8338	31	410 (38.1)		
	46	319 (29.6)	Net	
	65	243 (22.6)		

Remark: A special ATD is required for each membrane element.

# **Operating and Design Information**

Typical Operating Pressure	600-800PSI	
Maximum Operating Pressure	1200PSI	
M:	Continuous Operation: 50°C	
Maximum Temperature	Chemical Cleaning: 85°C	
A 11 I. 1 TT	Continuous Operation: 3-10	
Allowable pH	Chemical Cleaning: 3-9	
Maximum Pressure Drop	<15psi	
Chlorine Tolerance	500ppm/h,dechlor is recommended	
Maximum Feed Turbidity	<1NTU	
Maximum Feed SDI (15 minutes)	<5	

# **Nominal Dimensions**



Duo dinote	Dimensions-(in/mm)		
Products	A	В	C
Dairy-RO4-3838-31/46-C-0830	38 (965)	3.8 (97)	0.83 (21)
Dairy-RO4-3840-31/46-C-0830	40 (1016)	3.8 (97)	0.83 (21)
Dairy-RO4-6338-31/46/65-C-1139	38 (965)	6.3 (160)	1.139 (28.9)
Dairy-RO4-8038-31/46/65-C-1139	38 (965)	7.9 (200)	1.139 (28.9)
Dairy-RO4-8338-31/46/65-C-1139	38 (965)	8.3 (211)	1.139 (28.9)

#### Important information

- New spiral membranes must be cleaned prior to first use. The cleaning procedure should be in accordance with the instructions provided in the HMCT cleaning description for the spiral membrane concerned.
- The customer is fully responsible for the effects that any incompatible chemicals may have on the spiral membranes.
- After initial wetting, the spiral membranes must be kept moist at all times.
- If the operating specifications provided in this product description are not strictly followed, the limited warranty will be null and void.
- To prevent biological growth during system shutdowns, HMCT recommends that spiral membranes should be immersed in a protective solution.
- Avoid permeate-side back pressure at all times.
- HMCT recommends using a rigid stainless steel ATD end device at the housing outlet end.
- HMCT recommends that the inner diameter of the housing should be approx. 2 mm (0.08") bigger than the outer diameter of the spiral membrane.
- For storage conditions, please see Storage document.
- For warranties, please see spiral membrane warranty document.

#### **Operating guidelines**

HMCT recommends the following start-up procedure from standstill to operating condition:

- The unpressurized plant should be refilled with water.
- Feed pressure should be gradually increased over a 30 60 second time scale.
- Before initiating cross-flow at high permeate flux condition (start-up with high-temperature water) the set feed pressure should be maintained for 5 10 minutes.
- Cross-flow velocity at the set operating point should be gradually achieved over a period of 15
   20 seconds.
- Temperature variations should be implemented gradually over a period of 3 5 minutes.
- Avoid any abrupt pressure or cross-flow variations on the membranes during start-up, shutdown, cleaning or other sequences in order to prevent possible damage.

